


UXP-UPS5V

Example connection diagram



Quick Start

1. Connect internal battery jumper (1) **or** external battery
2. Connect 5 VDC power supply

WARNING
Do not connect internal and external battery at the same time.

The maximum total load is 2 A

Power Output
Any 5 VDC device, max 2 A
Optional. Only on selected models.

Power Output
Any 5 VDC device, max 2 A

Serial number